


Yükseklik (A)
 Çatı eğim hesabı : ----- x 100
 Taban (B)

SABİT SAÇAK ÇATI HESAP TABLOSU

EĞİM (%)	DERECE (°)	A	B	C
15	9°	15	100	33,54
20	11°	20	100	25,37
25	14°	25	100	20,51
30	17°	30	100	17,36
35	19°	35	100	15,10
40	22°	40	100	13,43
45	24°	45	100	12,16
50	27°	50	100	11,16
55	29°	55	100	10,35
60	31°	60	100	9,70
65	33°	65	100	9,15
70	35°	70	100	8,70
75	37°	75	100	8,32
80	39°	80	100	7,99
85	40°	85	100	7,70
90	42°	90	100	7,46
95	44°	95	100	7,24
100	45°	100	100	7,06



Yükseklik (A)
 Çatı eğim hesabı : ----- x 100
 Taban (B)

SERBEST SAÇAK ÇATI HESAP TABLOSU

EĞİM (%)	DERECE (°)	A	B	C
15	9°	15	100	4,58
20	11°	20	100	4,47
25	14°	25	100	4,38
30	17°	30	100	4,32
35	19°	35	100	4,24
40	22°	40	100	4,17
45	24°	45	100	4,13
50	27°	50	100	4,08
55	29°	55	100	4,05
60	31°	60	100	4,02
65	33°	65	100	4,00
70	35°	70	100	3,99
75	37°	75	100	3,99
80	39°	80	100	3,99
85	40°	85	100	4,00
90	42°	90	100	4,01
95	44°	95	100	4,03
100	45°	100	100	4,04